



# AIR CONDITIONING

## *Troubleshooting Tips*



**BEFORE  
CALLING  
FOR SERVICE,  
CHECK THE  
FOLLOWING:**

- Thermostat is set to “cool” and the temperature is set below the room temperature.
- Blower panel cover is installed correctly for the furnace blower (fan) to operate. Similar to the way a clothes dryer door operates, this panel pushes in a button that lets the fan motor know it is safe to come on. If that button is not pushed in, the furnace will not operate.
- Air conditioner and furnace breakers on the main electrical panel are on. (Remember if a breaker trips you must turn it from the tripped position to the off position before you can turn it back on.)
- 220 Switch on the outside wall near the air conditioner is on.
- Switch on the side of the furnace is on.
- Fuse in furnace is good (see manufacturer literature for size & location).
- Filter is in clean condition which allows air flow.
- Vents in individual rooms are open.
- Air returns are unobstructed.
- Air conditioner has not frozen from overuse.

If the troubleshooting tips do not identify a solution, the information you gather will be useful to the service provider you call.

Just a reminder the components of the air-conditioning system are covered by the manufacturers warranty and are excluded from the Classic Homes Limited Warranty. Classic is only responsible for Defects resulting from the original installation.

*-Classic Homes, Customer Service Team*